

# Anchorlift Stingray S1012 Mounting Template Scale 1:1

## Note!!

Before print:

Set printer page adjustment to non.

Before drilling:

Check measure on print.

Blue circle:

Cutout with hollow hole saw

Red line:

Cutout with jigsaw



